



Notes: Bulkheads, transom and stem fit inside 3/4" chine log + 1/4" sides  
 Deck panels cover 3/4" sheer clamps and 1/4" sides  
 If transom and stem are built of solid wood, make larger by 1/4" to cover plywood edges